



## FENDT


### Farmer 100-Serie

<b>104, 200</b>	01.72-05.82	Headlamp	<b>0 301 203 001</b>	R2,R2, T4W
				

### Farmer 200-Serie

	10.74 →	Headlamp	<b>0 301 203 001</b>	R2,R2, T4W
				

### Farmer 300-Serie

<b>305, 306, 308</b>	02.80-05.82	Headlamp	<b>0 301 203 001</b>	R2,R2, T4W
	02.80-12.92	Headlight, symmetrical	<b>0 301 204 002</b> <b>0 301 204 002</b>	R2,R2
	01.93 →	Headlight, symmetrical	<b>0 301 204 100</b> <b>0 301 204 100</b>	H4,H4
				

## FORD NEW HOLLAND (B)

### 8000-Serie

<b>8030, 8050, 8060, 8070, 8080</b>	11.86 →	Rear fog light	<b>0 313 103 006</b> <b>0 313 103 006</b>	
				

## HAMM

### DV

<b>10</b>	01.80 →	Headlamp	<b>0 301 203 001</b>	R2,R2, T4W
				



## GRW

<b>10, 15</b>	05.77 →	Headlamp	<b>0 301 201 002</b>	R2,R2, T4W
<b>30</b>	05.77 →	Headlamp	<b>0 301 203 001</b>	R2,R2, T4W

## KATO

### KR-Serie

<b>45H</b>	06.86 →	Headlamp	<b>0 301 017 003</b>	R2,R2, T4W
	06.86 →	Headlamp	<b>0 301 017 102</b>	H4,H4, T4W

## MERCEDES-BENZ

### Trac

<b>700, 800</b>	01.76-10.82	Headlamp	<b>0 301 201 002</b>	R2,R2, T4W
<b>1100, 1300, 1500, 900</b>	10.76-03.87	Headlamp	<b>0 301 203 001</b>	R2,R2, T4W





## NEW HOLLAND (SPERRY NEW HOLL.) (B)

### Serie 8000

8030, 8040, 8050, 8060, 8070, 8080

03.78-11.86

Rear fog light

0 313 103 006

0 313 103 006



## REFORMWERKE BAUER

### Reform

112, 115, 131

03.76-06.84

Headlight, symmetrical

0 304 101 003

0 304 101 003

